

## WHEELIE BIN STORE ASSEMBLY Page 1



### STEP 1

**Make sure you build the bin store on a level surface.**

**Screw the back panel to one of the side panels with 4mm x 70mm screws**



### STEP 2

**Screw the other side panel to the back panel with 4mm x 70mm screws**



### STEP 3

**Turn the unit on its back and nail the first 30" support strip to the underside at the front with the nails provided**



### STEP 4

**Nail the second 30" support strip to the underside at the back of the unit with the nails provided**



### STEP 5

**Stand the unit up and screw the top support brace inside the top front using 5mm x 100mm screws**

## WHEELIE BIN STORE ASSEMBLY Page 2



### STEP 6

**Holding the door level to the side palings, screw the hinges to the inside of the panel using 3mm x 20mm screws. The door can be hung on ether side.**



### STEP 7

**Screw the door fastener on to accept the pad bolt with 4mm x 30mm screws**



### STEP 8

**Rest the lid on top and screw the hinges on with 4mm x 30mm screws**



### STEP 9

**Nail the three facia strips on to the front of the unit with the nails provided**



### STEP 10

**Your wheelie bin store is now complete**